


Package Contents




Router × 1



Power Adapter × 1



Ethernet Cable × 1




Quick Start Guide × 1

Connect the Device

- Power off the modem, and remove the backup battery if it uses.
- Make sure that the router is close to a power outlet and near Ethernet cables for wired computers.
- Place the router horizontally and orient the antennas vertically.

ⓘ Images may differ from the actual product.



LED and Buttons

LED Patterns

• Flashing green	WPS mode
• Solid green	Internet connected
• Solid red	No Internet connectivity
• Green & Red	Updating firmware
• Off	Device is powered off/LED is turned off

Reset Button

Press and hold the button for more than 5s to reset the router to its factory mode.

WPS Button


Press the button for 1s to start the WPS process.

Set Up the Network

Method 1: Via a Web Browser

1. Connect your device to the router wirelessly or with an Ethernet cable.

   ⓘ • The default Wi-Fi network name (SSID) is printed on the label at the bottom of the router.
   • For security, change to a unique SSID and assign a password.



2. Launch a web browser. Key in **http://imouwifi.net** in the address bar. Read and accept the agreement and click Try Now.



3. Follow the on-screen instructions to set up the Internet connection.

Method 2: Via the Imou Life App


1. Download the Imou Life App.

Download on the App Store
GET IT ON Google Play
OR
Imou Life

2. Open the Imou Life App and log in.

   ⓘ If you are a new user, please register an account first.

3. Add your devices. Follow the instructions on the app to complete the setup and connect to the Internet.



FAQ

Q1: What should I do if I can't access the router's management page?

- Reboot your router and try again.
- Check your Wi-Fi connection.
- Use another Web browser such as Google Chrome.
- Restart your device.

Q2: What should I do if I can't access Internet?

- Reboot your modem and router, then try again.
- Check the Internet is working. With an Ethernet cable connecting the modem to the computer directly.

Q3: What should I do if I forget my Web management page password?


- Check the Web password on the label at the bottom of the router.
- When the router is power on, use a pin to press and hold the RESET button on the back until the LED blinks. Then the password will restore to the default that marked on the label.

Q4: What can I do if my Wi-Fi devices cannot connect over Wi-Fi to the router?

Please try to check:

- You have enabled the router's SSID network broadcast and displays in your Wi-Fi client's scanning list.
- You have entered the correct Wi-Fi password when connecting your devices to the Wi-Fi network.

If you failed to address the problem, you can reset the router to factory default settings.



For the user guide, support, and more information, please visit **https://www.imou.com/support**

Email **service.global@imoulife.com** to give suggestions.

Follow **@imouglobal** to get more brand information.

Dual-band Wi-Fi Router

Quick Start Guide

V1.0.0

1.29.02.U10046